ICON**S**
CLAMP

ICON**S** CLAMP

Easy and affordable access to compressor status information

ORIGINAL PART

Get access
to valuable
equipment status
information

WHY DO YOU NEED IT?

Thanks to the **IC**ON**S** clamp, monitoring
capabilities are now available for
compressors up to 30kW.

By showing you the service status of your
equipment, **IC**ON**S** makes on-time service
easier.

Connecting the ICONS Clamp to your
installation will provide you full visibility,
whatever the equipment type or brand.

It's simply the best way to ensure the
reliable performance of your compressed air
installation.

HOW DOES IT WORK?

Once attached, the **IC**ON**S** clamp gets
its power from the machine. No wires or
batteries needed!

By detecting the compressor's power
consumption, the clamp registers its running
hours and load/unload status.

These can be consulted on the user-friendly
ICON**S** platform.

3

SIMPLE STEPS

Step 1

Click the **IC**ON**S** Clamp around one of
the input phases of your compressor.

Step 2

Scan the QR code with your smartphone
or tablet and register.

Step 3

Open the **IC**ON**S** platform and start
monitoring your equipment.

https://portal.connectivityicons.com